



## The first steps:

If you would like to establish a *Bluetooth*® connection for the first time, you must activate the *Bluetooth*® function in your mobile telephone and start the search for *Bluetooth*® devices. Search for a device with the description "AD 9060". If several devices have been found, please select and connect the AD 9060 and enter the **PIN number`1234`**. The subsequent functions are described in the operating manual.



## Voice commands which are valid for all menus:

### Cancel

Ends the voice control function.

### Help

By saying Help you can hear the commands, which are available in each submenu.

### Back

One step back.

### Head menu

The main menu is open.

## The most important voice commands:

## Hauptmenü

### Dial Joe Blogs

Will not be displayed in the head menu.

Will not be displayed in the head menu. Direct call of a phonebook entry.

If you have saved more than one number for one person, you can dial directly via the category, e.g.

#### „Dial Joe Blogs home“

It is important to match the announced name exactly with the phone book entry.

### Dial number

- Digits (0..9)
- Playback
- Delete all
- Delete last
- Dial
- Delete group

Special symbols like +, \* and # can be actuated in the same way as the *Pause* function (space character) e. g. for mailbox functions.

### Phone book

- Select entry <digit>
- Playback
- Play list
- Select Joe Blogs
- Dial
- Dial fast search
- Get details
  - Dial home
  - Dial mobile
  - Dial office
  - Dial general
  - Dial SIM
  - Voice Tag
    - Store
  - Number
- Next
- Previous
- Next Page
- Previous Page

### Redial

Here, you can re-dial the telephone number which was most recently dialled with the hands-free car kit.

### Call lists

- Dialled calls
- Received calls
- Missed calls

In these menu items the following commands are available to you:

- Select entry <digit>
- Number
- Playback
- Dial
- Next
- Previous
- Next page
- Previous page





## Head menu

### Messages

### Read new message

### Settings

- All messages
- New messages

Will not be displayed in the head menu.

In these menu items the following commands are available to you:

- Select entry <digit>
- Playback
- Dial
- Read
- Next
- Previous
- Next page
- Previous page

With this voice prompt you can directly reach a new message.

- Bluetooth
- Phone list
- Clear list
- Pin code
  - Default
  - User
  - Accept
- Auto connect on / off
- Playback

- Voice dial
- Advanced help on / off
- Audio feedback an / aus
- Speaker adaptation
- Description




- Audio
- DSP
- Enable / Disable DSP
- Phone DSP
- Device DSP
- Echo suppression
- Playback
- Ringtones
- Volume
- Speech
- Ringtone
- More
- Less
- Maximum
- Minimum
- Accept
- Mute delay
- Playback
- Select entry <digit>

- Display
- Sleep mode
- Enable / Disable
- 15 seconds
- 30 seconds
- 60 seconds
- Illumination
- More
- Less
- Maximum
- Minimum
- Accept
- Day/Night mode
- Colour theme
- Calibration
- Playback

- Device
- Call answering
- Manual
- Automatic
- Voice
- Language
- Sync phone book
- System
- Version Info
- Software update
- Factory setting
- Yes
- No



### Handling via touch screen:

All displayed commands can also be operated intuitively via touch screen and are self explaining. Except more voice tags. **Read new message** and **Dial Joe Bloggs**. The operation can be carried out via possibly existing arrow keys. With the red symbols   you can cancel an action or go a step back. With the green symbol  you can confirm actions. In certain menus speech support is available. You can activate the audio feedback by touching the field Audio feedback in the menu Voice dial.