

COMFORT COMPACT BT OPERATION GUIDE

When you first turn on your Comfort Compact BT car-kit, the unit will DING and go into search mode for 40 seconds looking for the last known paired mobile phone.

INITIAL PAIRING PROCEDURE

Prepare your phone to detect a Bluetooth device.

Start the phone into search mode.

Follow the prompts on your phone. The pass key is 1234.

When paired the unit will give a tone indicating connection has been established.

TO CANCEL THE PAIRING PROCESS

Press the BT key once.

ANSWER A CALL

Press the BT key once.

VOLUME CONTROL

Each press of the (+) key will increase the volume. The device will DING when maximum volume is reached.

Each press of the (-) key will decrease the volume. The device will DING when minimum volume is reached.

CAR-KIT TO PRIVACY MODE

Hold the BT key for 3 seconds to shift call to phone. Press BT key once to reconnect with car-kit.

HANG UP A CALL

Press the BT key once.

LAST NUMBER REDIAL

Press the BT key twice.

VOICE TAGS

Press the BT key once (only for phones that store voice tags).

DISCONNECT FROM BLUETOOTH

Press & hold the BT key for 3 seconds when not in a call.

RECONNECT TO BLUETOOTH

Press the BT key once.

TURN DSP OFF/ON IN THE PHONE

Hold + and - keys for 4 seconds when a call is not in progress.

TURN DSP OFF/ON IN THE CAR-KIT

Hold + and - keys for 4 seconds when a call is in progress.

DSP MODES

If the party calling in experiences their voice echoing back to them please select the appropriate DSP option for the best call quality:

TURN DSP OFF/ON IN THE PHONE

When you are not in a call press and hold the + and - keys for 4 seconds.

1 beep – DSP is off in the phone

2 beeps – DSP is on in the phone]

TURN DSP OFF/ON IN THE CRADLE

When in a call press and hold the + and - keys for 4 seconds

1 beep – DSP is off in the car-kit

2 beeps – DSP is on in the car-kit